

### Eliminating Audio Hum

If an audio hum (60 cycle noise) is apparent on the radio, one or both of the following may lower the noise level.

1. Disconnect the 3rd ground prong from the power supply as plugged into the wall. Use of a 3 prong to 2 prong adapter is recommended. Note: Disconnecting the ground may effect coverage and broadcast range so this should be retested.



2. Open the unit by removing 4 Phillips Head screws in cover and cut away the internal brown ground wire as illustrated.

